






CL-04 LIFT LANDING DOOR RETIRING CAM MOUNTING-ADJUSTMENT-MAINTENANCE INSTRUCTIONS

MOUNTING-ADJUSTMENT

- 1) Take out the CL-04 Lift Landing Door Retiring Cam, that you have bought, from its box and make the control of the feeding voltage and its kind on the label number 1. If you are sure, that it is one and the same with the feeding voltage and the kind of current of your installation (system), continue the mounting.
- 2) During the mounting position, the arrows on the label number 1 must show upper direction, be careful.
- 3) Do the mounting of the magnet into its place in the lift cabin with the help of the slot holes, which are at the both ends of the below chassis number 2.
- 4) After completing the mounting, make the manual operation of the magnet, if there is any stitching or problem, contact to our company. If there isn't any problem during the manual operation, begin to do the electrical mounting.
- 5) Put the grounded cable where there is a grounding mark on below chassis number 2 by squeezing turnscrew number 6 on bolt number 5.
- 6) Put the ends of the other two cables (phase and neutral) in the free holes number 7 and by squeezing number 8 holes with a screwdriver, complete the electrical connection.
- 7) If it is possible, operate the magnet by application of voltage and control it.
- 8) For making the adjustment of the lock handle, there must be approximately free place of 3-5 mm between it and the lock handle when the CL-04 Lift Landing Door Retiring Cam is closed. Make the control, if this free space is absent, make the readjustment of the lock handle.
- 9) The operation course of the CL-04 Lift Landing Door Retiring Cam was adjusted as 33 mm. For its harmonious operation with the lock, make the lock handle adjustment carefully.
- 10) The operation speed of the CL-04 Lift Landing Door Retiring Cam can be adjusted. If it makes any sound when the lock is opening with a speedy operation, you can slow down the operation speed a little bit by squeezing the speed adjustment screw number 4, that is situated on the speed adjustment cylinder number 3.
- 11) The minimum decrease of the speed by complete squeezing of the speed adjustment screw is not advised, because the magnet causes extreme heating by decreasing the pulling power of the bobbin.
- 12) The useful life of the product is 10 (ten) years, Two (2) years guarantee.

MAINTENANCE

- 1) The dust, that was assembled in the operating parts, must be cleaned during the routine maintenance every month.
- 2) Because the oil on the operating shaft in the bobbin is heatproof oil, contact to our company, if it has to be oiled.
- 3) During the routine maintenance every month, make the control of the terms, described in the adjustment part. Redo the disassembled adjustment.
- 4) If any liquid comes to the operation environment due to cleaning or any other reason during the controls, provide the doing away of this environment. The liquids, that can enter into the bobbins and the electrical connections, can cause short circuits.
- 5) If the cabin needs to be painted, dismount the CL-04 Lift Landing Door Retiring Cam from its place. Remount it again after the painting procedure. Paints and solvents, that can enter in the operating parts, can damage the operation system.
- 6) Keep away from needless inventions, except cleaning, adjustment and the other ones, that were described in the above mentioned articles.
- 7) If necessary, contact with our company.





CAN-LIFT ÜRÜNLERİNİ TERCH ETTİĞİNİZ İÇİN TEŞEKKÜR EDERİZ

THANK YOU FOR CHOOSING CAN-LIFT PRODUCTS

ÜRETİCİ FİRMA - PRODUCER COMPANY

CAN-LIFT ASANSÖR SANAYİ ve TİC. LTD. ŞTİ.
İnönü Mah. Balçık Köyü Yolu Üzeri GEPOSB, İç 7. Cad.
No.6 41400 Gebze / Kocaeli / TÜRKİYE
Phone: +90 262 751 45 90 Pbx Fax: +90 262 751 45 50
www.canlift.com e-mail:info@canlift.com




CL-04 ASANSÖR DURAK KAPISI KİLİT AÇMA MAGNETİ MONTAJ-AYAR-BAKIM KILAVUZU

MONTAJ-AYAR TALİMATI

- 1) Almış olduğunuz CL 04 Asansör Durak Kapısı Kilit Açma Magnetini kutusundan çıkartınız. 1 nolu Etiketlin üzerindeki besleme gerilimini ve cinsini kontrol ediniz. Tesisatınızın besleme gerilimi ve akımı cinsi ile aynı olduğuna eminensiniz montaja devam ediniz.
- 2) Montaj pozisyonu sırasında 1 nolu etiket üzerindeki oklar yukarı gösterecek şekilde olmalıdır, dikkat ediniz.
- 3) Magneti 2 nolu Alt Şasenin iki ucunda bulunan slot delikler yardımı ile asansör kabinindeki yerine uygun civatalarla montaj ediniz.
- 4) Montaj tamamlandıktan sonra magneti el ile çalıştırınız, herhangi bir kasıntı veya olumsuzluk varsa firmamız ile temasa geçiniz. Elle çalışma sırasında sorun yok ise elektrik montajına geçiniz.
- 5) Topraklama kablosunu 2 nolu alt şase üzerinde topraklama işareti ile belirtilen bölgede 5 nolu civata üzerindeki 6 nolu somunu gevşeterek bağlayınız ve somunu yeterince sıkınız.
- 6) Diğer iki kablo (faz ve nötr) uçlarını da boşta kalan 7 nolu deliklere takınız ve tornavida ile 8 nolu deliklerden sıkarak elektrik bağlama işlemini bitiriniz.
- 7) Mümkünse gerilim uygulayarak magneti çalıştırarak kontrol ediniz.
- 8) Kilit kolu ayarı yapmak için CL 04 Asansör Durak Kapısı Kilit Açma Magneti kapalı iken kilit kolu ile arasında yaklaşık 3-5 mm boşluk olmalıdır. Kontrol ediniz eğer bu boşluk yok ise kilit kolunu tekrar ayarlayınız.
- 9) CL 04 Asansör Durak Kapısı Kilit Açma Magnetinin çalışma kursu 33 mm olarak ayarlanmıştır. Kilit ile uyumlu çalışabilmesi için kilit kol ayanını dikkatlice yapınız.
- 10) CL 04 Asansör Durak Kapısı Kilit Açma Magnetinin çalışma hızı ayarlanabilmektedir. Hızlı çalışma ile kilit açılarken ses yapıyorsa 3 nolu hız ayar silindiri üzerindeki 4 nolu hız ayar vidasını bir miktar sıkarak çalışma hızını yavaşlatabilirsiniz.
- 11) Hız ayar vidasının tamamen sıkılarak hızın minimuma düşürülmesi magnet bobininin çekme gücünde düşme yaparak aşırı ısınmaya neden olacağı için tavsiye edilmez.
- 12) Ürünün kullanım ömrü on (on) yıldır. Garanti süresi iki (2) yıldır.

BAKIM TALİMATI

- 1) Aylık rutin bakımlarda çalışan kısımlarda birikmiş tozlar temizlenmelidir.
- 2) Bobin içinde çalışan mil üzerindeki yağ ısıya dayanıklı olduğu için yağlanması gerekiyorsa firmamız ile iletişime kurunuz.
- 3) Aylık rutin bakımlarda ayar kısmında anlatılan şartları denetleyiniz. Bozulmuş ayarları tekrar yapınız.
- 4) Kontroller sırasında çalışma ortamına temizlik yada herhangi bir sebeple sını geldiği tespit edilirse bu ortamın iyi edilmesini sağlayınız. Bobin içine ve elektrik bağlantılarına girecek sıvılar kısa devre yapmasına neden olabilir.
- 5) Kabinin boyanması gereken durumlarda CL 04 Asansör Durak Kapısı Kilit Açma Magnetini yerinden sökünüz. Boya işleminin sonra tekrar montaj ediniz. Çalışan kısımlara girecek boya ve çözücüler çalışma sistemine zarar verebilir.
- 6) Temizlik ve ayar haricinde yukarıda anlatılan maddelerden başka gereksiz müdahalelerden kaçınız.
- 7) Gerekli olduğu durumlarda şirketimiz ile iletişime kurunuz.



CAN-LIFT ÜRÜNLERİNİ TERCİH ETTİĞİNİZ İÇİN TEŞEKKÜR EDERİZ

THANK YOU FOR CHOOSING CAN-LIFT PRODUCTS

ÜRETİCİ FİRMA - PRODUCER COMPANY

CAN-LIFT ASANSÖR SANAYİ ve TİC. LTD. ŞTİ.

İnönü Mah. Balçık Köyü Yolu Üzeri GEPOSB, İç 7. Cad.

No.6 41400 Gebze / Kocaeli / TÜRKİYE

Phone: +90 262 751 45 90 Pbx Fax: +90 262 751 45 50

www.canlift.com e-mail:info@canlift.com